


# EVOLUTION RDS AM/FM TUNER



Designed and engineered  
in the United Kingdom

## Instruction Manual



Thank you for purchasing the Creek Evolution tuner. You are now in possession of a State of the Art RDS AM/FM tuner. The Evolution is the matching tuner for the Evolution Integrated Amplifier and CD Player, although it will also work very well with any other manufacturers' amplifiers. The functions and operation of the Evolution tuner are deceptively simple for the many features that it offers, all of which can be remotely controlled.

### SAFETY REQUIREMENTS

Read all the instructions before connecting or operating the unit. Keep this manual so you can refer to these safety instructions.

### WATER & MOISTURE

To reduce the risk of fire or electric shock, do not expose the unit to moisture or water. If the unit is exposed to moisture, immediately disconnect the power cord from the wall. Take the unit to an authorised service centre for inspection. Do not touch the unit, power cord, or plug with wet hands.

### VENTILATION

You must allow 5 cm (2 inches) of unobstructed clearance around the unit. Do not place the unit on a bed, sofa, rug, or similar surface that could block ventilation from the bottom.

### HEAT

Keep the unit away from naked flames, radiators, stoves, or any other heat-producing appliances (including amplifiers).

### RACK & STANDS

Place the unit on a fixed, level surface strong enough to support its weight, such as the Creek Audio Rack. Do not place it on a moveable device that could tip over.

### CLEANING

Unplug the unit from the mains supply before cleaning. The case should normally require only a wipe with a soft lint-free cloth.

### POWER SOURCES

Only connect the unit to a power supply of the type and voltage described in the operating instructions or specified on the rear panel of the unit.

### POWER CORD PROTECTION

Connect the unit to the power outlet only with the cord supplied. Do not modify the supplied cable in any way. Do not attempt to defeat grounding and/or polarisation provisions. Do not use extension cords. Do not route the power cord where it will be crushed, pinched, bent at severe angles, exposed to heat, or damaged in any way.

### NON-USE PERIODS

If the unit is to be left unused for a long period of time, the power cord should be unplugged from the wall outlet.

## SAFETY REQUIREMENTS cont'd.

### DAMAGE REQUIRING SERVICE


Stop using the unit immediately and have it inspected by an authorised service centre whenever...

1. The power supply cord or plug has been damaged.
2. Liquid has been spilled into the unit.
3. The unit has been exposed to rain.
4. The unit does not operate properly.
5. The unit has been dropped or damaged.
6. Smoke or any unusual smell is detected from the unit.

### CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER-SERVICEABLE PARTS INSIDE.

### REAR PANEL



### CONNECTING TO OTHER EQUIPMENT

#### INTERCONNECT CABLES

To connect the tuner to an amplifier an interconnect cable is required. Any cable of reasonable quality terminated with RCA plugs will be suitable. Please consult your dealer if you are unsure.

#### AUDIO OUTPUT

These outputs are located on the back of the Evolution Tuner and are labelled ANALOGUE OUTPUT. Connect these outputs to the amplifier's tuner input. Match the Red interconnect lead to the R-ANALOGUE OUTPUT and the White interconnect lead to the L-ANALOGUE OUTPUT.


#### ANTENNA

One FM and one AM antenna are supplied. Connect the AM (two wire loop) antenna to the AM antenna clips on the rear panel. Connect the FM antenna (single piece of wire) to the FM 75 Ohm connection on the rear panel. To obtain the best FM or AM signal use a high quality directional external antenna. If in doubt consult your supplying dealer for advice.

#### MAINS CONNECTION

Check that the power button on the front of the unit is in the off position. Push the plug (IEC line socket) of the power cable supplied with the Evolution Tuner into the socket (AC IN) on the rear of the unit. Make sure it is pressed in firmly. Plug the other end of the power cable into an AC wall outlet.

### FRONT PANEL



### FRONT PANEL CONTROLS & OPERATION

#### POWER

Press this button to turn the tuner on and off.

#### TUNING

Turn the knob left or right to manually fine tune stations after switching Mode to tuning. When tuned to the maximum frequency, it is possible to go to the minimum frequency quickly by continuing to turn the knob clockwise. The frequency will flip to the bottom 87.5Mhz on FM.

## **PRE-SET**

Steps up or down through pre-set stations by turning the knob on the right after switching Mode to Pre-set. When using Pre-set mode, after reaching the last stored station in FM, the tuner will flip to any stored stations in AM, then back to FM if the knob is turned back or forward through all of the stored AM stations.

## **MODE**

Press this button to select manual tuning or pre-set mode, when using the 32mm knob on the right of the panel. The button toggles between the 2 functions and the display will either show the pre-set station number, say 12F, for the station pre-set 12, or it will show 00F at the beginning to indicate free tuning and not pre-set.

## **SCAN**

Press to scan up the radio dial from the lowest frequency. Press once to automatically search for the next tuned (strong) station. If you want to keep it press the memory button once. The letters Mem will flash in the display and the next available pre-set number will be shown. If you still want to keep it, press the memory button again.

## **STORE**

Use to set a station pre-set. Tune to the station you wish to save as a pre-set. Press the STORE button. The band (FM or AM) and a pre-set number will be displayed and begin to flash. Turn the tuning/preset knob on the front panel until the desired number is displayed. Press the STORE button again to save the station and corresponding preset. Any number 1- 80 can be used for AM or FM pre-sets. Pre-sets can be set faster by using the remote control.

## **BAND**

Press to toggle through FM auto/stereo, FM mono, and AM bands. FM auto/stereo is shown by the appearance Auto and Stereo at the top of the display. Auto will disappear and Mono will change to Stereo when a station is tuned in stereo and the signal strength is great enough to support it, noise free.

## **USING THE REMOTE CONTROL**

Note: Install the two AAA batteries supplied with the remote control.

The Evolution handset is a system remote control and therefore not all buttons control the Evolution tuner. To use the remote control with the Evolution tuner make sure the CD/TUNER button is in the up position. Buttons that function with the tuner are shown in green type on the handset. CD player buttons are shown in grey against a black background. Some buttons are dual use and will have both grey and green descriptions. Refer to the Evolution CD manual for CD player button descriptions. Do not place anything in front of the display area of the unit, or the remote control may not work.

## **BUTTONS NUMBERED 0-9**

Allow direct access to station pre-sets. To select a pre-set station, press the corresponding numbered button/s. In a few moments, the tuner will automatically move to the pre-set entered.

## **SCAN**

This button does not function with the Evolution tuner.

## **REP/--**

Press to directly tune to a station. Enter the station's frequency using the buttons numbered 0-9. The keystrokes for entering the station's frequency are different for AM and FM stations, see below.

Please note; the tuner must be on the desired band (AM or FM) of the station you are trying to select. If it is not, select the appropriate band prior to proceeding.

## **TUNING**

Press to tune up or down the radio dial. Press and hold to automatically search up or down to the next tuned (strong) station.

## **PROG/MEM**

Use to set a station pre-set. Tune to the station you wish to save as a pre-set. Press the MEMORY button. The band (FM or AM) and a pre-set number will be displayed and begin to flash. Use the buttons numbered 0-9 to select a preset number or press the preset button on the remote control to select a preset number. Press PROG/MEM again to save the station and corresponding preset. Any number from 1-80 can be used for AM or FM presets.

## **DISPLAY**

Press the display button to choose between three levels of brightness on the display.

## **AUTO**

Press to automatically select and store all stations that are available in your area into the tuner's memory, in all wavebands. To avoid accidentally doing this if you have already stored all your required selection manually, the Auto function requires the button to be pressed for 3 seconds or more to enable it.

## WARRANTY

If within two years of purchase date your Evolution Tuner proves to be defective for any reason other than accident, misuse, neglect, unauthorised modification, or fair wear and tear, Creek Audio Ltd. will, at its discretion, replace the faulty parts without charge for labour or return carriage within the U.K. This warranty is valid only in the U.K. and given in addition to statutory rights. Service enquiries outside the U.K. should be addressed first to the supplying dealer and/or the Creek distributor/importer. Warranties granted in these countries are entirely at the discretion of the distributor. Distributor details can be found by visiting the Creek Audio website.

## TECHNICAL SPECIFICATIONS

### FM

Frequency range	87.5 - 108.0 MHz
Frequency response	15Hz to 12kHz +/- 1dB
Usable sensitivity at 30dB	S/N = 30dB 90MHz FM = 9dBu
Selectivity (IHF)	30dB
Signal to noise ratio @90MHz,	60dBu and 75kHz mod = 56db
Distortion (mono)	40 kHz mod = 1%
Stereo separation @ 1kHz	40dB mod = 39dB
Output level @ 75kHz	mod = 1.2 V RMS
Number of pre-sets	80 for AM and FM

### AM

Frequency range	520 - 1720 USA 531 - 1620 Rest of World
Usable sensitivity at 20dB	S/N and 30dB mod = 36dB
S/N ratio at 30dB	mod = 36dB
Distortion @ 30dB	mod = 1.2%
Output level	1.0V RMS
Number of pre-sets	80 for AM and FM

Power dissipation 230/115V 15 Watts maximum

Size W x H x D 430 x 75 x 330 mm (17" x 3" x 13")

Weight 5 kgs (11 lbs)

### Supplied Accessories

Mains lead

Remote control with 2 AAA batteries

FM antenna - piece of wire

AM antenna - 2 wire loop antenna

USA This product complies with FCC requirements

Europe CE

China CCC

Australia C Tick

---

Creek Audio Limited  
12 Avebury Court  
Mark Road  
Hemel Hempstead HP2 7TA  
England

Tel: +44 (0) 1442 260146  
Fax: +44 (0) 870 6220846  
Email: [info@creekaudio.com](mailto:info@creekaudio.com)  
URL [www.creekaudio.com](http://www.creekaudio.com)