





CAS 4040 Din Inputs/Outputs:

Aux Din Plug




Pins 5R and 3L are Inputs to the pre-amp.
Pins 4R and 1L are Outputs from the pre-amp.
Pin 2 is an Earth.

Tuner Din Plug



Pins 5R and 3L are Inputs to the pre-amp.
Pins 4R and 1L are not used.
Pin 2 is an Earth.

Tape Din Plug



Pins 5R and 3L are Inputs to the pre-amp.
Pins 4R and 1L are Outputs to the Tape recorder.
Pin 2 is an Earth.